



PO Box 548
Charlevoix, Michigan 49720
United States
(231) 437-0200 *phone*
(231) 308-5905 *fax*
www.bedlamcreations.com

Vinyl Decals
Graphic Design
Website Design
Video Editing

Let us **expand** your mind...

RUB-ON DECAL APPLICATION INSTRUCTIONS

Tools Required:

- Sharp Scissors
- Plastic Squeegee / Coin (or other device to rub decal transfer with)

Tools Recommend:

- Kylon Crystal Clear Acrylic Coating #1303

Each decal has three pieces:

1. The top layer is the transfer tape.
2. The middle layer is the printed decal film.
3. The bottom layer is the backing tape.

You should read these instructions all the way through before starting. The surface must be clean, and free of all oils, waxes and dirt. These decals come to you in three layers. The top layer is called transfer tape. It looks like transparent tape. The middle layer is the actual decal. The bottom layer is a transparent backing tape treated with a release agent.

Application:

Remove decal sheet from packaging gently. Cut out decal using a small sharp pair of scissors leaving as little space as possible between the decal print and cutting edge. Store remainder of decal sheet in supplied packaging this will prevent oils and moisture from coming in contact with sheet.

Carefully remove the backing tape from the decal. Apply decal to clean dry surface with the graphic faced down avoiding air holes. Rub decal aggressively with plastic squeegee, finger nail, coin, or wooden stick making sure all air bubbles are removed.

Carefully peel off the transfer tape starting at a corner making sure that the decal and print as been applied to the application surface.

Optional Clear Coating:

To protect decals, spray over decal with an acrylic clear coating spray. We suggest Krylon Crystal Clear Acrylic Coating #1303, we can not guarantee the performance of any other clear coat. You must first apply 2-3 very thin mist coats over the decal; allowing it to dry each time. After you have sealed the decal with thin coats you may apply a heavy coat.

Removing Rub-On Decals:

You can remove rub-on decals by placing decal in hot water for 10-20 minutes and peel off with finger nail. If hot water is not available or practical depending on what the decal was applied to then you may heat up the decal using a hair dryer and peel with finger nail.

Final Note:

The application of rub-on decals requires patience, however they are much easier then waterslide decals. If this is your first time applying a rub-on decal, please try some samples first. We cannot be responsible for replacing decals that have been damaged during application.